


Wheel Measurement



<u>Rotor Diameter</u>	<u>"A" Dimension</u>	<u>Bottom of Caliper</u>	<u>Top of Caliper</u>
345 mm (13.6") Rear	23 mm (0.9")	116 mm (4.6")	203 mm (8.0")
355 mm (14.0") 4P-Frt	40 mm (1.6")	119 mm (4.7")	203 mm (8.0")
355 mm (14.0") 6P-Frt	40 mm (1.6")	119 mm (4.7")	213 mm (8.4")

Example: 13.6" Rear & 14" Front for Chrysler 300 or Dodge Charger or Magnum

- With a straight edge measure from the middle of the center bore out to 116 mm for the Rear Kit and 119 mm for the Front Kits to locate the bottom of the caliper.
- Now measure down from the straight edge to the back of the wheel spoke for the Kit's "A" measurement. **The Rear Kit needs 23 mm or more and the Front Kits needs 40 mm or more for the "A" dimension** to clear the caliper.
- Repeat these (2) steps for the caliper clearance through to the top of the caliper.